
ERSATZTEILLISTE OL 400 SPARE PARTS LIST OL 400


ZEICHNUNG 1 - DRUCKEREINHEIT (FIGURE 1 - PRINTER UNIT)



LISTE 1 - DRUCKEREINHEIT (TABLE 1 - PRINTER UNIT)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO	
1	PAPER CASSETTE	OPTION	
2	OPERATOR PANEL ASSY	4YA4083-5012G1	
4	LOWER UNIT	1YX4083-2002G1	
5	UPPER UNIT (120V)	1YX4083-2060G1	
	UPPER UNIT (220V)	1YX4083-2060G2	
7	OZONE FILTER	3PB4083-2816P2	
8	FACE-UP STACKER ASSY	2PA4083-2055G1	
9	FAN COVER	2PP4016-6836P1	
10	UPPER COVER	1PP4016-6830P7	
11	BUTTON	3PP4016-6832P1	
12	SHAFT	2PP4016-6831P1	
13	COVER SPRING	4PP4016-6833P1	
14	RESET SPRING	4PP4083-2585P1	
15	STACKER COVER ASSY	2PA4016-6834G1	
16	CASSETTE COVER	1PA4083-2321G1	
	CASSETTE COVER (LEGAL ONLY)	1PA4083-2321G2	


ZEICHNUNG 2 - OBERE EINHEIT (1/2) (FIGURE 2 - UPPER UNIT, 1/2)



LISTE 2 - OBERE EINHEIT (1/2) (TABLE 2 - UPPER UNIT, 2/2)

2 FUSING UNIT (120V) 2YX4083-2073G1 FUSING UNIT (240V) 2YX4083-2073G4 3 TONER CAETRIDGE OPTION 4 IMAGE DRUM CARTRIDGE OPTION 5 FUSER PAD 3PB4083-2096P1 8 PRESSURE SPRING 4PP4083-2091P1 (FUSING UNIT) 9 PRESSURE SPRING LB-191200-5 10 SENSOR LEVER (RESIST) 4PP4083-2068P1 11 SENSOR FLAG (RESIST) 3PP4083-2069P1 12 SENSOR LEVER (TONER) 4PP4083-2732G1 13 RIVET 4PP4083-2578P1 14 PAPER EIECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EIECT SENSOR LEVER C 4PP4083-2578P1 16 ACTUATOR 4PP4083-2589P1 17 IDLE GEAR 4PP4083-2095P1 18 FULCRUM BLOCK 3PP4083-2095P1 19 PRESSURE ROLLER 4PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2092P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER 4PP4083-2848P1 22 PRESSURE SPRING 4PP4083-2071P2 23 WIRE CLEANER 4PP4083-2072P1 24 TORSION SPRING L 4PP4083-2072P1 25 TORSION SPRING L 4PP4083-2093P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2065P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2063P1 30 LOCK LEVER R 3PP4083-2066P1 31 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2066P1 35 HEAT SHIELD 3PP4083-2066P1 36 PAPER GUIDE FILM (A) 4PP4083-2095P1	NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
3 TONER CARTRIDGE O P T I O N 4 IMAGE DRUM CARTRIDGE O P T I O N 5 FUSER PAD 3PB4083-2096P1 8 PRESSURE SPRING (FUSING UNIT) 4PP4083-2091P1 9 PRESSURE SPRING LB-191200-5 10 SENSOR LEVER (RESIST) 4PP4083-2068P1 11 SENSOR LEVER (TONER) 4PP4083-2069P1 12 SENSOR LEVER (TONER) 4PP4083-2732G1 13 RIVET 4PP4083-2578P1 14 PAPER EIECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EIECT SENSOR LEVER C 4PP4083-2578P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-2095P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2819P1 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2075P1 23 WIRE CLEANER 4PP4083-2075P1 24 TORSION SPRING R	2	FUSING UNIT (120V)	2YX4083-2073G1
4 IMAGE DRUM CARTRIDGE O P T I O N 5 FUSER PAD 3PB4083-2096P1 8 PRESSURE SPRING (PUSING UNIT) 9 PRESSURE SPRING LB-191200-5 10 SENSOR LEVER (RESIST) 4PP4083-2068P1 11 SENSOR FLAG (RESIST) 3PP4083-2099P1 12 SENSOR LEVER (TONER) 4PP4083-2732G1 13 RIVET 4PP4083-2584P1 14 PAPER EIECT SENSOR LEVER B 4PP4083-258P1 15 PAPER EIECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-2095P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2091P1 20 BEARING 4PP4083-2071P2 21 PRESSURE SPRING 4PP4083-2071P2 22 PRESSURE SPRING 4PP4083-2071P2 23 WIRE CLEANER 4PP4083-2071P2 24 TORSION SPRING 4PP4083-2072P1 25 TORSION SPRING 4PP4083-2093P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2093P1 27 SUPPORT PLATE L 3PP4083-2063P1 28 LOCK LEVER R 3PP4083-2063P1 30 LOCK LEVER R 3PP4083-2063P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK2-6-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2066P1 35 HEAT SHIELD 3PP4083-2066P1 36 PAPER GUIDE FILM (A) 4PB4083-2055P1		FUSING UNIT (240V)	2YX4083-2073G4
5 FUSER PAD 3PB4083-2096P1 8 PRESSURE SPRING (FUSING UNIT) 4PP4083-2091P1 9 PRESSURE SPRING LB-191200-5 10 SENSOR LEVER (RESIST) 4PP4083-2068P1 11 SENSOR LEVER (RESIST) 3PP4083-2069P1 12 SENSOR LEVER (TONER) 4PP4083-2732G1 13 RIVET 4PP4083-2584P1 14 PAPER EJECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2589P1 17 IDLE GEAR 4PP4083-2095P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-294P1 20 BEARING 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2072P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2093P1 26 GROUND PLATE (IMAGE DRUM)	3	TONER CARTRIDGE	OPTION
8	4	IMAGE DRUM CARTRIDGE	OPTION
FUSING UNIT PRESSURE SPRING LB-191200-5 SENSOR LEVER (RESIST) 4PP4083-2068P1 SENSOR FLAG (RESIST) 3PP4083-2069P1 SENSOR LEVER (TONER) 4PP4083-2732G1 RIVET 4PP4083-2584P1 PAPER EJECT SENSOR LEVER B 4PP4083-2578P1 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 ACTUATOR 4PP4083-2589P1 ACTUATOR 4PP4083-2095P1 DLE GEAR 4PP4083-3130P1 BEARING 4PP4083-2092P1 PRESSURE ROLLER 4PP4083-2092P1 PRESSURE ROLLER GEAR 4PP4083-2092P1 PRESSURE ROLLER GEAR 4PP4083-2071P2 PRESSURE SPRING 4PP4083-2071P2 PRESSURE SPRING 4PP4083-2072P1 PRESSURE SPRING 4PP4083-2072P1 AUTORSION SPRING L 4PP4083-2093P1 FORSION SPRING R 4PP4083-2093P1 CANCOLUMN OF THE RESION OF T	5	FUSER PAD	3PB4083-2096P1
10 SENSOR LEVER (RESIST) 4PP4083-2068P1 11 SENSOR FLAG (RESIST) 3PP4083-2069P1 12 SENSOR LEVER (TONER) 4PP4083-2732G1 13 RIVET 4PP4083-2584P1 14 PAPER EJECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-22092P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2071P2 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2072P1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2062P1 28 LOCK LEVER R 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN	8		4PP4083-2091P1
11 SENSOR FLAG (RESIST) 3PP4083-2069P1 12 SENSOR LEVER (TONER) 4PP4083-2732G1 13 RIVET 4PP4083-2584P1 14 PAPER EJECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-22848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-201P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2075P1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK1.6-8-SUS 32 KNOCK-PIN NK1.6-8-SU	9	PRESSURE SPRING	LB-191200-5
12 SENSOR LEVER (TONER) 4PP4083-2732G1 13 RIVET 4PP4083-2584P1 14 PAPER EJECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-201P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2075P1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2065P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2065P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK1.6-8-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P	10	SENSOR LEVER (RESIST)	4PP4083-2068P1
13 RIVET 4PP4083-2584P1 14 PAPER EJECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2072P1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2093P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2064P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2061P1 34 UPPER FRAME (LED HEAD) 1PP4083-206	11	SENSOR FLAG (RESIST)	3PP4083-2069P1
14 PAPER EJECT SENSOR LEVER B 4PP4083-2578P1 15 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2072P1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2064P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1-6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB40	12	SENSOR LEVER (TONER)	4PP4083-2732G1
15 PAPER EJECT SENSOR LEVER C 4PP4083-2589P1 16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2093P1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK1.6-8-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2055P1 <td>13</td> <td>RIVET</td> <td>4PP4083-2584P1</td>	13	RIVET	4PP4083-2584P1
16 ACTUATOR 4PP4083-2095P1 17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-219P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK1.6-8-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2098P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1 <	14	PAPER EJECT SENSOR LEVER B	4PP4083-2578P1
17 IDLE GEAR 4PP4083-3130P1 18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2064P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2098P1 35 HEAT SHIELD 3PB4083-2098P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	15	PAPER EJECT SENSOR LEVER C	4PP4083-2589P1
18 FULCRUM BLOCK 3PP4083-2092P1 19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER SHAFT 4PP4083-2064P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	16	ACTUATOR	4PP4083-2095P1
19 PRESSURE ROLLER 4PP4083-2848P1 20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2062P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	17	IDLE GEAR	4PP4083-3130P1
20 BEARING 4PP4083-2071P2 21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2062P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	18	FULCRUM BLOCK	3PP4083-2092P1
21 PRESSURE ROLLER GEAR 4PP4083-2819P1 22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	19	PRESSURE ROLLER	4PP4083-2848P1
22 PRESSURE SPRING 4PP4083-2072P1 23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	20	BEARING	4PP4083-2071P2
23 WIRE CLEANER 4PP4083-2757G1 24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	21	PRESSURE ROLLER GEAR	4PP4083-2819P1
24 TORSION SPRING L 4PP4083-2093P1 25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	22	PRESSURE SPRING	4PP4083-2072P1
25 TORSION SPRING R 4PP4083-2094P1 26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	23	WIRE CLEANER	4PP4083-2757G1
26 GROUND PLATE (IMAGE DRUM) 4PP4083-2067P1 27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	24	TORSION SPRING L	4PP4083-2093P1
27 SUPPORT PLATE L 3PP4083-2065P1 28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	25	TORSION SPRING R	4PP4083-2094P1
28 LOCK LEVER R 3PP4083-2062P1 29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	26	GROUND PLATE (IMAGE DRUM)	4PP4083-2067P1
29 LOCK LEVER L 3PP4083-2063P1 30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	27	SUPPORT PLATE L	3PP4083-2065P1
30 LOCK LEVER SHAFT 4PP4083-2064P1 31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	28	LOCK LEVER R	3PP4083-2062P1
31 KNOCK-PIN NK2-16-SUS 32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	29	LOCK LEVER L	3PP4083-2063P1
32 KNOCK-PIN NK1.6-8-SUS 33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	30	LOCK LEVER SHAFT	4PP4083-2064P1
33 GROUND PLATE (RESIST) 4PP4083-2066P1 34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	31	KNOCK-PIN	NK2-16-SUS
34 UPPER FRAME (LED HEAD) 1PP4083-2061P1 35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	32	KNOCK-PIN	NK1.6-8-SUS
35 HEAT SHIELD 3PB4083-2998P1 36 PAPER GUIDE FILM (A) 4PB4083-3055P1	33	GROUND PLATE (RESIST)	4PP4083-2066P1
36 PAPER GUIDE FILM (A) 4PB4083-3055P1	34	UPPER FRAME (LED HEAD)	1PP4083-2061P1
	35	HEAT SHIELD	3PB4083-2998P1
DADED GLIDE ELLM (D)	36	PAPER GUIDE FILM (A)	4PB4083-3055P1
37 PAPER GUIDE FILM (B) 4PB4083-3056PI	37	PAPER GUIDE FILM (B)	4PB4083-3056P1


ZEICHNUNG 3 - OBERE EINHEIT (2/2) (FIGURE 3 - UPPER UNIT, 2/2)



LISTE 3 - OBERE EINHEIT (2/2) (TABLE 3 - UPPER UNIT, 2/2)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO	
1	LED HEAD	4YA4083-2230G1	
6	CLAMP SPRING (LED HEAD)	4PP4083-2099P1	
7	BIAS SPRING	4PP4083-2088P1	
35	LED HOLDER	1PP4083-2087P1	
36	KNOB L	3PP4083-2594P1	
37	KNOB R	3PP4083-2595P1	
38	PRESSURE SPRING	4PP4083-2596P1	
39	GROUND PLATE (LED HEAD)	4PP4083-2090P1	


ZEICHNUNG 4 - UNTERE EINHEIT (1/2) (FIGURE 4 - LOWER UNIT, 1/2)



LISTE 4 - UNTERE EINHEIT (1/2) (TABLE 4 - LOWER UNIT, 2/2)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO	
1	PAPER SUPPLY UNIT (TYPE B)	4YA4083-2124G1	
2	PULSE MOTOR (MAIN)	4PB4083-2041P1	
3	RESIST ROLLER	3PA4083-2897G1	
3A	BUSH FOR RESIST ROLLER ASSY	4PP4083-2006P1	
4	TRANSFER CHARGER ASSY	3PA4083-3142G1	
5	BACKUP ROLLER ASSY	4PA4083-2896G1	
6	IDLE GEAR A	4PP4083-2593P1	
7	REDUCTION GEAR	3PP4083-2044P1	
8	IDLE GEAR B	4PP4083-3130P1	
9	CASSETTE SPRING	4PP4083-2295P1	
10	IDLE GEAR	4PP4083-2045P1	
11	POST	4PP4083-2046P1	
12	PRESSURE SPRING	4PP4083-2023P1	
13	DC FAN ASSY	270A2230P0001	
23	BIAS ROLLER	4PP4083-2760P1	
24	BIAS SPRING L	4PP4083-2776P1	
25	BIAS SPRING R	4PP4083-2777P1	
26	MOTOR COVER	2PP4083-2575P1	
27	MOTOR BRACKET	4PP4083-3059G1	
28	HIGH VOLTAGE CONNECTOR	3PB4083-2108P1	
29	CAP	3PP4083-2588P1	
30	DISELECTRIFICATION CLOTH	4PB4083-2938P1	
31	FUSING GUIDE	3PP4083-2566G1	
32	SHEET GUIDE	3PP4083-2035P1	
33	BASE FRAME	1PP4083-2003P1	


ZEICHNUNG 5 - UNTERE EINHEIT (2/2) (FIGURE 5 - LOWER UNIT, 2/2)



LISTE 5 - UNTERE EINHEIT (2/2) (TABLE 5 - LOWER UNIT, 2/2)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO	
14	POWER SUPPLY UNIT (120V)	4YA4083-5017G7	
	POWER SUPPLY UNIT (220V)	4YA4083-5017G8	
14A	HIGH VOLTAGE BOARD ASSY	4YB4049-1469P1	
15	LLAB PCB (ENGINE CONTROLLER)	4YA4021-1054G100	
16	LLIE PCB	3PU4003-5942P1	
17	LBPE PCB (MAIN CONTROLLER)	4YA4078-1163G2	
	LBPK PCB (MAIN CONTROLLER)	4YA4046-1553G1	
18	LLCQ PCB (CENTRONICS I/F)	4YA4046-1429G1	
	LLRS PCB (RS-232 C I/F)	4YA4078-1129G1	
19	RAMK PCB (1MB)	4YA4078-1160G1	
20	AC COVER	4PP4083-2103P1	
21	CONTACT PLATE AC	4PP4083-2048P1	
34	BOARD COVER	3PP4083-2742P1	
35	POST	4PP4083-2847P1	
36	SHIELD PLATE ASSEMBLY (A)	3PA4083-2570G2	
37	SHIELD PLATE ASSEMBLY (B)	2PP4083-2051P1	
38	MICRO SWITCH ASSY 120V	4YX4056-3735G1	
	MICRO SWITCH ASSY 220V	4YX4056-3735G3	
39	EEPROM (FOR LLAB PCB)	4YA4083-5010G1	
40	GROUND PLATE (FOR TYPE A POWER SUPPLY)	4PP4083-2005P1	

ZEICHNUNG 6 - PAPIERAUSGABEEINHEIT (FIGURE 6 - PAPER EJECT ROLLER ASSY)




KOMPLETT: 2YX4083-2026G1 EXIT ROLLER ASSY

LISTE 6 - PAPIERAUSGABEEINHEIT (TABLE 6 - PAPIER EJECT ROLLER ASSY)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO	
1	SHEET GUIDE	2PP4083-2027P1	
2	PAPER EJECT ROLLER	4PB4083-2028P1	
3	PAPER EJECT ROLLER (FACE UP)	4PP4083-2515P1	
4	PAPER EJECT ROLLER SHAFT	3PP4083-2029P1	
5	IDLE GEAR (PAPER EJECT)	4PP4083-2344P1	
6	E-CLIP	RE6-SUS	
7	SENSOR LEVER (PAPER EJECT)	3PP4083-2032P1	
8	SHEET SEPARATOR	3PP4083-2881P1	


ZEICHNUNG 7 - PAPIERZUFÜHREINHEIT (TYPE A) (FIGURE 7 - PAPER SUPPLY UNIT, TYPE A)



LISTE 7 - PAPIERZUFÜHREINHEIT (TYPE A) (TABLE 7 - PAPER SUPPLY UNIT, TYPE A)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
1	LLCC PCB	4YA4083-5011G1
2	PULSE MOTOR (RESIST)	4PB4083-3186P1
3	SEPARATOR	4PP4083-2255G1
4	HOPPING ROLLER ASSY	4PA4083-3105G1
5	SEPARATOR SPRING	4PP4083-2270P1
6	HOPPING GEAR	3PP4083-2265P1
7	PLANET GEAR	4PP4083-2282P1
8	IDLE GEAR A	4PP4083-2278P1
9	IDLE GEAR	4PP4083-2043P1
10	PAPER END LEVER	3PP4083-2268P1
11	IDLE CAM	3PP4083-2573P1
12	FEED ROLLER	4PP4083-2574P1
13	ESCAPE LEVER	3PP4083-2256P1
14	MOTOR BRACKET	4PP4083-3057G1
15	UPPER PLATE	2PP4083-2269P1
16	HOPPING ROLLER SHAFT	3PP4083-3092P1
17	E-CLIP	RE6-SUS
18	SIDE FRAME L ASSY	3PA4083-2562G1
19	SIDE FRAME R	1PP4083-2252P1
20	SEPARATOR FRAME	1PP4083-2253P1
21	SETTING LEVER	3PP4083-2266P1
22	LATCH LEVER	4PP4083-2267P1
23	LATCH SPRING	4PP4083-2271P1
24	LATCH SHAFT	4PP4083-2296P1


ZEICHNUNG 8 - PAPIERZUFÜHREINHEIT (TYPE B) (FIGURE 8 - PAPER SUPPLY UNIT, TYPE B)



LISTE 8 - PAPIERZUFÜHREINHEIT (TYPE B) (TABLE 8 - PAPER SUPPLY UNIT, TYPE B)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO
1	LLCC PCB	4YA4083-5011G1
2	PULSE MOTOR (RESIST)	4PB4083-2275P1
3	SEPARATOR	4PP4083-2255G1
4	HOPPING ROLLER ASSY	4PA4083-3105G1
5	SEPARATOR SPRING	4PP4083-2270P1
6	HOPPING GEAR	3PP4083-2265P1
7	PLANET GEAR	4PP4083-2282P1
8	IDLE GEAR A	4PP4083-2278P1
9	IDLE GEAR	4PP4083-2043P1
10	PAPER END LEVER	3PP4083-2268P1
12	HOPPING ROLLER B	3PP4083-2261P1
13	ESCAPE LEVER	3PP4083-2256P1
14	MOTOR BRACKET	4PP4083-3057G1
15	UPPER PLATE	2PP4083-2269P1
16	HOPPING ROLLER SHAFT	3PP4083-3092P1
17	E-CLIP	RE6-SUS
18	SIDE FRAME L ASSY	3PA4083-2562G1
19	SIDE FRAME R	1PP4083-2252P1
20	SEPARATOR FRAME	1PP4083-2253P1
21	SETTING LEVER	3PP4083-2266P1
22	LATCH LEVER	4PP4083-2267P1
23	LATCH SPRING	4PP4083-2271P1
24	LATCH SHAFT	4PP4083-2296P1
25	F. G. PLATE	4PP4083-2272P1

ZEICHNUNG 9 - 2. PAPIEREINZUGSMECHANIK (FIGURE 9 - SECOND PAPERTRAY)



LISTE 9 - 2. PAPIEREINZUGSMECHANIK (TABLE 9 - SECOND PAPERTRAY)

NR. NO.	BEZEICHNUNG PART NAME	BESTELL-NR. PART NO	
1	SECOND PAPER TRAY UNIT	1YX4083-2285G2	·
2	LLFC PCB (SECOND TRAY CONTROLLER)	4YA4083-5015G2	
3	LLIF PCB (CONNECTION)	4YA4046-1496G1	
4	LLIG PCB (CONNECTION)	3PU4009-1238P1	
5	CONNECTOR PM8DOX	224A1282P0081	
6	CONNECTOR AKJ-40AG	224A1157P0401	
7	LOWER BASE	1PP4016-6791P1	